

Table of Contents

6.	LOOP WITH NUMBER PORTABILITY _____	3
6.1	INTRODUCTION _____	3
6.2	LOOP WITH NUMBER PORTABILITY ADMINISTRATIVE SECTION _____	4
1.	PON - Purchase Order Number _____	4
2.	VER - Version Identification _____	5
3.	AN - Account Number _____	6
4.	ATN - Account Telephone Number _____	7
5.	LQTY - Loop Quantity _____	8
6.	NPQTY - Number Portability Quantity _____	9
7.	PG_of_ - Page _ of _ _____	10
6.3	LOOP WITH NUMBER PORTABILITY SERVICE DETAILS SECTION _____	11
8.	LOCNUM - Location Number _____	11
9.	LNUM - Line Number _____	12
10.	NPI - Number Portability Indicator _____	13
11.	LNA - Line Activity (Loop) _____	14
12.	LNA - Line Activity (Number Portability) _____	16
13.	RL – Reuse Loop _____	18
14.	LMT – Loop Modification Type _____	19
15.	BTRL - Bridged Tap Removal Location _____	20
16.	CKR - Customer Circuit Reference _____	21
17.	TSP - Telecommunications Service Priority _____	22
18.	TNT – Test and Tag Requested _____	23
19.	LRN - Location Routing Number _____	24
20.	TDT – Ten Digit Trigger _____	25
21.	SAN - Subscriber Authorization Number _____	26
22.	ECCKT - Exchange Company Circuit ID _____	27
23.	OECCKT – Out Exchange Company Circuit ID _____	28
24.	RESID - Response Identifier _____	29
25.	CFA - Connecting Facility Assignment _____	30
26.	CCEA – Cross Connect Equipment Assignment _____	32
27.	SYSTEM ID - System Identification _____	33
28.	CTI – Connection Type Indicator _____	34
29.	CABLE ID - Cable Identification _____	35
30.	CBCID – Cross Box Cable Identification _____	36
31.	SHELF - Shelf _____	37
32.	SLOT - Slot _____	38
33.	SPORT - Slot Port _____	39
34.	RELAY RACK – Relay Rack _____	40
35.	CHAN/PAIR - Channel/Pair _____	42
36.	UNIT – Unit _____	43
37.	JK CODE - Jack Code _____	44
38.	IWT - Inside Wire Type _____	45
39.	JK NUM – Jack Number _____	46
40.	JK POS - Jack Position _____	47
41.	JR - Jack Request _____	48
42.	NIDR - NID Request _____	49
43.	IWJK - Inside Wire Jack Code _____	50

44.	IWJQ - Inside Wire Jack Quantity	51
45.	PORTED NBR – Ported Telephone Number	52
46.	TNP - Total Number of Paths	53
47.	CFTN - Call Forward To Number	54
48.	NPT - Number Portability Type	55
49.	RTI - Route Index	56
50.	NPTG - Number Portability Trunk Group	57
51.	LSCP – Local Service Provider Change Prohibited	58
52.	BA – Blocking Activity	59
53.	BLOCK - Block	60
54.	FPI - Freeze PIC Indicator	61
55.	LPIC - IntraLATA Pre-subscription Indicator Code	62
56.	TC OPT - Transfer of Call Options	63
57.	TC TO PRI - Transfer of Calls To Primary Number	64
58.	TC TO SEC - Transfer of Calls To Secondary Number	65
59.	TCID - Transfer of Calls To Identifier	66
60.	TC NAME - Transfer of Calls To Name	67
61.	TC PER - Transfer of Calls Period	68
62.	LEAN - Line Existing Account Number	69
63.	LEATN - Line Existing Account Telephone Number	70
64.	REMARKS - Remarks	71
65.	SOE REMARKS – SOE Remarks	72

6. LOOP WITH NUMBER PORTABILITY

6.1 INTRODUCTION

1. This guide describes the Loop Service with Number Portability (LSNP) Form entries. The LSNP Form must always be associated with LSR and EU Forms, which contain administrative, bill detail and location information necessary for the provisioning of this request. The field entries contained within the LSNP Form are to be provided by the customer.

6.2 LOOP WITH NUMBER PORTABILITY ADMINISTRATIVE SECTION

1. PON - Purchase Order Number

Identifies the customer’s unique purchase order or requisition number that authorizes the issuance of this request or supplement.

INTERFACE	Field Name
IRES	PON
FTP	PON

NOTE 1: The purchase order number can not be reused.

USAGE: See usage strip below.

ACTIVITIES												
R E Q		N	C	D	T	V	W	S	B	L	P	
	B/LNP	P	P	R	P	R	P	P	P	P	P	P
	B/INP	P	P	R	P	R	P	P	P	P	P	

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation.

DATA CHARACTERISTICS: 16 alphanumeric characters

EXAMPLE: | 8 | 2 | 4 | Z | 9 | | | | | | | | | | | | | |

2. VER - Version Identification

Identifies the customer’s version number.

Interface	Field Name
IRES	VER
FTP	Not applicable

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	R	P	R	P	P	P	P	p

NOTE 1: The VER is auto-populated by IRES.

NOTE 2: IRES will increment the VER field by 1 when a SUP is submitted.

DATA CHARACTERISTICS: 2 numeric characters

EXAMPLES: | 1 | 2 |

| 8 | |

3. AN - Account Number

Identifies the main account number assigned by the NSP.

Interface	Field Name
IRES	Not Applicable
FTP	Not Applicable

NOTE 1: This field is the Sprint LTD end users main telephone number assigned by Sprint LTD and represents an account that has not been migrated to another customer.

NOTE 2: This field is used to recognize the main telephone number that must be preordered in order to obtain all other associated telephone numbers.

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	P	P	R	P	P	P	P	P

NOTE 1: This field is supported for manual processing only.

DATA CHARACTERISTICS: 10 numeric characters (excluding 2 preprinted hyphens)

EXAMPLE:

2	0	1
---	---	---

 -

5	5	5
---	---	---

 -

1	2	1	2
---	---	---	---

4. ATN - Account Telephone Number

Identifies the account telephone number assigned by the NSP.

Interface	Field Name
IRES	TEL NO
FTP	TN

NOTE 1: This field describes all telephone numbers associated with the AN field.

NOTE 2: All numbers requesting migration must be supplied.

NOTE 3: When processing manually, each telephone number must be listed on a separate form.

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	R	P	R	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation.

NOTE 2: This field will be auto-populated in IRES based on preorder information.

DATA CHARACTERISTICS: 10 numeric characters (excluding 2 preprinted hyphens)

EXAMPLE: | 2 | 0 | 1 | - | 5 | 5 | 5 | - | 1 | 2 | 1 | 2 |

5. LQTY - Loop Quantity

Identifies the quantity of loops involved in this service request.

Interface	Field Name
IRES	LOOP QTY
FTP	LQTY

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	R	P	R	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation.

NOTE 2: Depending on REQ/ACT combination, field may be auto-populated in IRES.

DATA CHARACTERISTICS: 4 numeric characters

EXAMPLES:

			1
--	--	--	---

6. NPQTY - Number Portability Quantity

Identifies the quantity of ported numbers involved in this service request.

Interface	Field Name
IRES	NP QTY
FTP	NPQTY

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	R	P	R	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation.

NOTE 2: Depending on REQ/ACT combination, field may be auto-populated in IRES.

DATA CHARACTERISTICS: 4 numeric characters

EXAMPLES:

				1
--	--	--	--	---

7. PG_of_ - Page _ of _

Identifies the page number and total number of pages contained in this request.

Interface	Field Name
IRES	Not Applicable
FTP	Not Applicable

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	R	P	R	P	P	P	P	P

DATA CHARACTERISTICS: 4 numeric characters

EXAMPLE: PG 1 of 2

6.3 LOOP WITH NUMBER PORTABILITY SERVICE DETAILS SECTION

8. LOCNUM - Location Number

Identifies the service location number for the service requested.

USAGE: This field is not supported by Sprint LTD.

9. LNUM - Line Number

Identifies the line or trunk as a unique number and each additional occurrence as a unique number.

Interface	Field Name
IRES	LNUM
FTP	Not Applicable

NOTE 1: The LNUM is customer assigned for manual requests and is returned on the Local Response (LR) Form to the ordering customer.

NOTE 2: Once LNUM is assigned manually, it may be changed by Sprint LTD.

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	R	P	R	P	P	P	P	P

NOTE 1: Field is auto-populated in IRES based on telephone numbers preordered.

DATA CHARACTERISTICS: 4 numeric characters

EXAMPLE:

0	0	0	1
---	---	---	---

10. NPI - Number Portability Indicator

Identifies the status of the telephone number being ported.

USAGE: This field is not supported by Sprint LTD.

11. LNA - Line Activity (Loop)

Identifies the activity involved at the line level.

Interface	Field Name
IRES	LNA
FTP	LLNA

NOTE 1: This field is used to describe the LNA associated with the Loop.

VALID ENTRIES:

- B = Restore
- C = Change an existing account, e.g., rearrangement, partial disconnect or addition
- D = Disconnection
- H = Short term
- L = Seasonal
- M = Inside move of the physical termination within a building
- N = New installation and/or account
- P = PIC change
- R = Record activity is for ordering administrative changes
- S = Suspend
- T = Outside move of end user location
- V = Conversion of service to new LSP as specified
- W = Conversion as is
- X = Telephone number change
- Y = Deny

NOTE 1: “B”, “C”, “H”, “L”, “M”, “R”, “P”, “S”, “T”, “W”, “X” and “Y” are not supported by Sprint LTD.

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	R	P	R	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation.

NOTE 2: When ACT=V, valid Loop LNA values are “N” and “V.”

NOTE 3: When ACT=D and NPT=B (INP) the only valid Loop LNA value is “D.”

When ACT=D, NPT=B both loop & NP must be disconnected

DATA CHARACTERISTICS: 1 alpha character

EXAMPLE:

N

12. LNA - Line Activity (Number Portability)

Identifies the activity involved at the line level.

Interface	Field Name
IRES	LNA
FTP	NPLNA

NOTE 1: This is a Sprint LTD proprietary field.

NOTE 2: This field is used to describe the LNA associated with Number Portability.

VALID ENTRIES:

- B = Restore
- C = Change an existing account, e.g., rearrangement, partial disconnect or addition
- D = Disconnection
- H = Short term
- L = Seasonal
- M = Inside move of the physical termination within a building
- N = New installation and/or account
- P = PIC change
- R = Record activity is for ordering administrative changes
- S = Suspend
- T = Outside move of end user location
- V = Conversion of service to new LSP as specified
- W = Conversion as is
- X = Telephone number change
- Y = Deny

NOTE 1: “B”, “C”, “D”, “H”, “L”, “M”, “N”, “P”, “R”, “P”, “S”, “T”, “W”, “X” and “Y” are not supported by Sprint LTD for NP/LNP.

NOTE 2: “B”, “C”, “H”, “L”, “M”, “N”, “P”, “R”, “P”, “S”, “T”, “W”, “X” and “Y” are not supported by Sprint LTD for NP/INP.

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	R	P	R	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation.

NOTE 2: When ACT=V, valid NP LNA values for B/LNP and B/INP are “V.”

NOTE 3: When ACT=D, valid NP LNA value for B/INP is “D.”

DATA CHARACTERISTICS: 1 alpha character

EXAMPLE:

N

13. RL – Reuse Loop

Identifies the customers desire to reuse the loop from an existing service arrangement for this request.

USAGE: This field is not supported by Sprint LTD.

14. LMT – Loop Modification Type

Identifies the loop changes involved in this service request.

USAGE: This field is not supported by Sprint LTD.

15. BTRL - Bridged Tap Removal Location

Identifies the location of the bridged tap to be removed from the loop.

USAGE: This field is not supported by Sprint LTD.

16. CKR - Customer Circuit Reference

Identifies the circuit number or sequential range of circuit numbers assigned by the customer.

Interface	Field Name
IRES	CKR
FTP	CKR

NOTE 1: CKR is used by the customer as a cross-reference to the provider circuit ID and in many cases to identify the customer's end to end service.

USAGE: This field is not supported by Sprint LTD.

NOTE 1: This field appears in IRES, but currently is not supported for Loop with Number Portability.

17. TSP - Telecommunications Service Priority

Indicates the provisioning and restoration priority as defined under the TSP Service Vendor Handbook.

Interface	Field Name
IRES	TSP
FTP	TSP

NOTE 1: These codes are assigned by the TSP Program Office.

VALID ENTRIES:

- Nine character TSP control identifier
- One character provisioning priority level (E, 0-5)
- One digit restoration priority level (0-5)

NOTE 1: A TSP code ending in “00” indicates “revocation”, the removal of a previously assigned TSP code.

USAGE: See usage strip below.

ACTIVITIES											
R		N	C	D	T	V	W	S	B	L	P
E		O	O	O	O	O	P	P	P	P	P
Q	B/LNP	O	O	O	O	O	P	P	P	P	P
	B/INP	O	O	O	O	O	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation

DATA CHARACTERISTICS: 30 alphanumeric characters (including 1 hyphen)

EXAMPLE: | T | S | P | 1 | 2 | 3 | 4 | 5 | C | - | E | 1 |

18. TNT – Test and Tag Requested

Identifies the customer is requesting additional testing and tagging beyond that which is included with the product ordered.

Interface	Field Name
IRES	LOOPTAG/CTEST
FTP	LOOPTAG/CTEST

USAGE: Refer to Section 2 - LSR Section.

19. LRN - Location Routing Number

Identifies a number used to uniquely identify a switch that has ported numbers and is used to route a call to the switch that owns the NPA-NXX portion of the LRN.

Interface	Field Name
IRES	LRN
FTP	Not Applicable

USAGE: This field is not supported by Sprint LTD.

NOTE 1: This field appears in IRES, but currently is not supported.

20. TDT – Ten Digit Trigger

Indicates the request for the activation of a ten digit trigger for local routing number portability.

Interface	Field Name
IRES	TDT
FTP	TDT

NOTE 1: When ten digit trigger is requested, the request for the number port will occur at 11 p.m.

VALID ENTRIES:

Y = Yes

USAGE: See usage strip below.

ACTIVITIES											
REQ		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	O	P	P	P	P	P
	B/INP	P	P	P	P	P	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation.

NOTE 2: When this field usage is conditional (C), it will be prohibited if TDT field is populated, otherwise optional.

DATA CHARACTERISTICS: 1 alpha character

EXAMPLE:

21. SAN - Subscriber Authorization Number

Identifies a number equivalent to the end user purchase order number.

USAGE: This field is not supported by Sprint LTD.

22. ECCKT - Exchange Company Circuit ID

Identifies a provider’s circuit identification.

Interface	Field Name
IRES	ECCKT
FTP	ECCKT

- NOTE 1:** The format of the field is defined by the provider.
- NOTE 2:** All components within the ID should be delimited by periods.
- NOTE 3:** The layout of the field may be defined by the COMMON LANGUAGE standards.
- NOTE 4:** When a component of CLT, CLS and CLF is purposely omitted, the component should still be delimited and compressed to eliminate any spaces.
- NOTE 5:** If all positions in a component of CLT, CLS and CLF are not populated, the component should be compressed to eliminate any spaces.

VALID ENTRIES:

SERIAL NUMBER FORMAT:

Prefix/service code and modifier/serial number/suffix code/AP code/segment name (if applicable)

This format may be up to 27 characters in length.

EXAMPLE: 77.UCFS.123456..CTRL

USAGE: See usage strip below.

ACTIVITIES											
R		N	C	D	T	V	W	S	B	L	P
E	B/LNP	P	P	P	P	O	P	P	P	P	P
Q	B/INP	P	P	O	P	O	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation

DATA CHARACTERISTICS: 41 alphanumeric characters

23. OECCKT – Out Exchange Company Circuit ID

Identifies the circuit identification that was previously provided to the old LSP/NSP-Switch by the NSP-Loop.

Interface	Field Name
IRES	OECCKT
FTP	Not Applicable

USAGE: This field is not supported by Sprint LTD.

NOTE 1: This field appears in IRES, but currently is not supported for Loop with Number Portability.

24. RESID - Response Identifier

Identifies the response number assigned by the provider to relate associated transactions.

USAGE: This field is not supported by Sprint LTD.

25. CFA - Connecting Facility Assignment

Identifies the provider carrier system and channel to be used.

Interface	Field Name
IRES	CFA
FTP	CFA

NOTE 1: The format and structure of this field is defined by ANSI in document T1.238, Identification of Telecommunication Facilities for the North American Telecommunications System. The Facility Identifier consists of the following elements:

1. **Facility Designation** – A code that, for a specific type of facility, uniquely identifies a path between two network nodes (variable length, 1-5 alphanumeric characters).
2. **Facility Type** – A code that describes a type of facility when it is other than a single baseband channel on cable. Valid entries are outlined in Telcordia Technologies document BR-795-450-100 (variable length, 1-6 alphanumeric characters).
3. **Channel/Pair/Time Slot** – A code that identifies a specific assignable portion of a facility (variable length, 1-5 alphanumeric characters).
4. **Location A** – A standardized code that uniquely identifies the location of facility terminal A, which has the lower in alphanumeric sequence of the two facility location codes. Valid values are outlined in Telcordia Technologies document BR-795-100-100 (8 or 11 alphanumeric characters).
5. **Location Z** – A standardized code that uniquely identifies the location of facility terminal Z, which has the higher in alphanumeric sequence of the two facility location codes. Valid values are outlined in Telcordia Technologies document BR-795-100-100 (8 or 11 alphanumeric characters).

NOTE 2: Either virgules (/) or periods (.) are used consistently as delimiters to separate all elements of the CFA.

NOTE 3: All element entries of the CFA are left justified with no trailing spaces.

NOTE 4: Applicable when utilizing Hi-Cap facilities and the customer has assignment control.

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	O	P	P	P	P	P
	B/INP	P	P	O	P	O	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation.

DATA CHARACTERISTICS: 41 alphanumeric characters

EXAMPLES: |1|0|1|/|T|1|/|3|/|B|S|T|N|M|A|G|T|C|G|O|/|
B	S	T	N	M	A	M	T	C	G	O										
1	0	1	.	T	1	.	3	.	B	S	T	N	M	A	G	T	C	G	O	.
B	S	T	N	M	A	M	T	C	G	O										

26. CCEA – Cross Connect Equipment Assignment

Identifies the physical point of termination at a collocation arrangement.

USAGE: This field is not supported by Sprint LTD.

27. SYSTEM ID - System Identification

Identifies the customer's system to be used in a collocation arrangement.

USAGE: This field is not supported by Sprint LTD.

28. CTI – Connection Type Indicator

Identifies the configuration of the facility connection assignment.

USAGE: This field is not supported by Sprint LTD.

29. CABLE ID - Cable Identification

Identifies the provider's cable to be connected to the customer's equipment in a central office location.

Interface	Field Name
IRES	CABLE ID
FTP	CABLEID1, CABLEID2, CABLEID3, CABLEID4

NOTE 1: Applicable when the customer has assignment control.

NOTE2: Up to four iterations may be requested.

NOTE 3: An iteration will consist of cable id, channel pair and may or may not consist of CTI.

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	P	P	R	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation.

NOTE 2: First iteration of Cable ID is required.

NOTE 3: If NCI field begins with 04, the second iteration of Cable ID is required.

NOTE 4: If there is a 2nd iteration, the 1st iteration must be present. If there is a 4th iteration, 1st, 2nd and 3rd iterations must be present.

DATA CHARACTERISTICS: 5 alphanumeric characters

EXAMPLE: | X | X | X | 0 | 1 |

30. CBCID – Cross Box Cable Identification

Identifies the provider's cable to be connected to the customer's terminal in a field location.

USAGE: This field is not supported by Sprint LTD.

31. SHELF - Shelf

Identifies the number assigned to the shelf within the relay rack.

Interface	Field Name
IRES	SHELF
FTP	SHELF

NOTE 1: Applicable when the customer has assignment control in a collocation arrangement.

NOTE 2: May be applicable when the customer has assignment control of the POTS line splitter in a line sharing or line splitting arrangement.

USAGE: See the usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	P	P	R	P	P	P	P	P

NOTE 1: Optional when the RELAY RACK field is populated, otherwise prohibited.

NOTE 2: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation

DATA CHARACTERISTICS: 6 alphanumeric characters

EXAMPLE:

2	0				
---	---	--	--	--	--

32. SLOT - Slot

Identifies the specific connection slot of the shelf to be used.

Interface	Field Name
IRES	SLOT
FTP	SLOT

NOTE 1: Applicable when the customer has assignment control in a collocation arrangement.

NOTE 2: May be applicable when the customer has assignment control of the POTS line splitter in a line sharing or line splitting arrangement.

USAGE: This field is conditional.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	P	P	R	P	P	P	P	P

NOTE 1: Optional when the SHELF field is populated, otherwise prohibited.

NOTE 2: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation

DATA CHARACTERISTICS: 4 alphanumeric characters

EXAMPLE: | 0 | 7 | | |

33. SPORT - Slot Port

Identifies the specific connection port of the slot to be used.

USAGE: This field is not supported by Sprint LTD.

34. RELAY RACK – Relay Rack

Identifies the bay/cabinet in a central office and may include the floor and aisle where the specific piece of equipment is located.

Interface	Field Name
IRES	RELAY RACK
FTP	RELAYRACK

NOTE 1: The format and structure of this field is defined by Telcordia Technologies document BR 751-100-785. The Relay Rack consists of the following elements:

1. **Floor/Level** – Character positions one (1) and two (2) outline the Floor or Level value. This data element is a mnemonic code that consists of certain combinations of alpha, numeric and special characters. It defines a particular floor/level where frames are located. Valid entries are outlined in Telcordia Technologies document BR 751-100-785. (2 alphanumeric characters)
2. **Line-Up/Frame Function** – Character positions three (3) through seven (7) identify either a Line-Up or Frame Function. When this data element contains Line-Up data, it is a particular row of relay equipment in a central office. A Frame Function Code identifies the various frames, racks, bays and cabinets installed in a central office. Valid entries are outlined in Telcordia Technologies practice BR 751-100-785. (1-5 alphanumeric characters)
3. **Bay Number** – Character positions eight (8) and nine (9) identify the Bay Number. This data element is a numeric code that identifies various bays or frames within a central office. Valid entries are outlined in Telcordia Technologies document BR 751-100-785. (2 numeric characters)
4. **Bay Designation** – Character position ten (10) identifies the Bay Designation. This data element is 1 character that identifies the Front, Back or marker group of the switching system. Valid entries are outlined in Telcordia Technologies document BR 751-100-785. (1 alpha character)

NOTE 2: Applicable when the customer has assignment control in a collocation arrangement.

NOTE 3: May be applicable when the customer has assignment control of the POTS line splitter in a line sharing or line splitting arrangement.

USAGE: See usage strip below.

ACTIVITIES												
R E Q		N	C	D	T	V	W	S	B	L	P	
	B/LNP	O	O	O	O	O	O	P	P	P	P	P
	B/INP	O	O	O	O	O	O	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation.

DATA CHARACTERISTICS: 10 alphanumeric characters

EXAMPLE: | 0 | A | - | - | - | - | 3 | 0 | 2 | |

NOTE 1: The example indicates the Second Level below surface, Line-Up 3, Bay 2.

| 1 | 7 | | | 1 | 1 | 8 | 1 | 2 | F |

NOTE 1: The example indicates Floor 17, Line-Up 118, Bay 12, Front.

35. CHAN/PAIR - Channel/Pair

Identifies the specific channel or pair within the provider's cable to be used for connection.

Interface	Field Name
IRES	CHAN PAIR
FTP	CHANPAIR1, CHANPAIR2, CHANPAIR3, CHANPAIR4

NOTE 1: Applicable when the customer has assignment control.

NOTE 2: Up to four iterations may be requested when the CABLE ID field is populated; however, only one iteration may be provided per CABLE ID.

NOTE 3: Up to four iterations may be requested when the CBCID field is populated; however, only one iteration may be provided per CBCID field.

USAGE: See usage strip below.

ACTIVITIES											
R		N	C	D	T	V	W	S	B	L	P
E	B/LNP	P	P	P	P	R	P	P	P	P	P
Q	B/INP	P	P	O	P	R	P	P	P	P	P

NOTE 1: Required when the SYSTEM ID field, or the associated CABLE ID or the CBCID field is populated, otherwise prohibited.

NOTE 2: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation

NOTE 3: First iteration of Chan Pair is required.

NOTE 4: If NCI field begins with 04, the second iteration of Chan Pair is required.

NOTE 5: If there is a 2nd iteration, the 1st iteration must be present. If there is a 4th iteration, 1st, 2nd and 3rd iterations must be present.

DATA CHARACTERISTICS: 7 alphanumeric characters

EXAMPLE:

2	4					
---	---	--	--	--	--	--

36. UNIT – Unit

Identifies the number assigned to a panel, shelf or case within the customer's bay/cabinet indicated in the RELAY RACK field.

USAGE: This field is not supported by Sprint LTD.

37. JK CODE - Jack Code

Indicates the standard code for the particular registered or non-registered jack used to terminate the service.

USAGE: This field is not supported by Sprint LTD.

38. IWT - Inside Wire Type

Identifies the type of inside wiring to be used.

USAGE: This field is not supported by Sprint LTD.

39. JK NUM – Jack Number

Identifies the number of the jack used on end user connections.

USAGE: This field is not supported by Sprint LTD.

40. JK POS - Jack Position

Identifies the position in the jack that a particular service will occupy.

USAGE: This field is not supported by Sprint LTD.

41. JR - Jack Request

Indicates a request for a new jack.

USAGE: This field is not supported by Sprint LTD.

42. NIDR - NID Request

Indicates a request for a new Network Interface Device (NID).

Interface	Field Name
IRES	NIDR
FTP	NIDR

VALID ENTRIES:

Y = Yes

USAGE: See usage strip below.

ACTIVITIES												
R E Q		N	C	D	T	V	W	S	B	L	P	
	B/LNP	P	P	P	P	O	P	P	P	P	P	P
	B/INP	P	P	P	P	O	P	P	P	P	P	

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation.

DATA CHARACTERISTICS: 1 alpha character

EXAMPLE:

43. IWJK - Inside Wire Jack Code

Indicates the standard code for the type of jack requested for inside wiring.

USAGE: This field is not supported by Sprint LTD.

44. IWJQ - Inside Wire Jack Quantity

Indicates the number of jacks requested for inside wiring.

USAGE: This field is not supported by Sprint LTD.

45. PORTED NBR – Ported Telephone Number

Identifies the Telephone Number (TN) or consecutive range of TNs residing in the same switch to be ported.

Interface	Field Name
IRES	PORTED #
FTP	PORTEDNBR

NOTE 1: A single telephone number that is to be ported.

NOTE 2: This telephone number may be a customer or Sprint LTD number.

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	R	P	R	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation.

NOTE 2: When ACT=D for B/INP, this field will contain a customer telephone number.

NOTE 3: This field will be auto-populated in IRES based on preorder information.

DATA CHARACTERISTICS: 10 numeric characters (excluding 2 preprinted hyphens)

EXAMPLES: |9|0|8| - |6|9|9| - |7|0|0|0|

46. TNP - Total Number of Paths

Identifies the total number of talk paths, including the initial path, associated with the ported number.

Interface	Field Name
IRES	TNP
FTP	TNP

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	P	P	P	P	P	P
	B/INP	P	P	O	P	R	P	P	P	P	P

NOTE 1: Required when the LNA field is "V" and the NPT field is "B", otherwise optional.

NOTE 2: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation

DATA CHARACTERISTICS: 3 numeric characters

EXAMPLE:

0	0	1
---	---	---

47. CFTN - Call Forward To Number

Identifies the telephone number to which calls will be directed.

Interface	Field Name
IRES	CFTN
FTP	CFTN

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	P	P	P	P	P	P
	B/INP	P	P	O	P	R	P	P	P	P	P

NOTE 1: For usage related to FTP, refer to Sprint FTP SIBR and supporting documentation

DATA CHARACTERISTICS: 10 numeric characters (excluding 2 pre-populated hyphens).

EXAMPLES:

9	1	3	-	7	9	4	-	9	9	9
---	---	---	---	---	---	---	---	---	---	---

48. NPT - Number Portability Type

Indicates the type of number portability for this request.

Interface	Field Name
IRES	NPT
FTP	Not Applicable

VALID ENTRIES:

- A = DID
- B = RCF (INP)
- C = Route index
- D = Local Number Portability

NOTE 1: “A” and “C” are not supported by Sprint LTD.

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	R	P	P	P	P	P
	B/INP	P	P	O	P	R	P	P	P	P	P

DATA CHARACTERISTICS: 1 alpha character

EXAMPLE: A

49. RTI - Route Index

Identifies the routing index to be used by the provider's switching equipment to forward/port the provider's telephone number to the customer's non-RCF trunk group.

USAGE: This field is not supported by Sprint LTD.

50. NPTG - Number Portability Trunk Group

Identifies the Two Six Code (TSC) of a dedicated trunk group, from the porting switch to the customer's Point Of Interface (POI), used to complete NP calls.

USAGE: This field is not supported by Sprint LTD.

51. LSCP – Local Service Provider Change Prohibited

Identifies that the end user has requested the option of prohibiting the change of their current service provider or removing the option.

USAGE: This field is not supported by Sprint LTD.

52. BA – Blocking Activity

Indicates the activity for the blocking of calls.

USAGE: This field is not supported by Sprint LTD.

53. BLOCK - Block

Identifies the type of blocking on the telephone number.

USAGE: This field is not supported by Sprint LTD.

54. FPI - Freeze PIC Indicator

Indicates the customer's requested freeze option.

USAGE: This field is not supported by Sprint LTD.

55. LPIC - IntraLATA Pre-subscription Indicator Code

Identifies the Pre-subscription Indicator Code (PIC) of the carrier the customer has selected for IntraLATA traffic.

USAGE: This field is not supported by Sprint LTD.

56. TC OPT - Transfer of Call Options

Identifies the type of transfer of call option the end user has requested.

Interface	Field Name
IRES	TC OPT
FTP	TCOPT

USAGE: See Section 3 - End User.

57. TC TO PRI - Transfer of Calls To Primary Number

Identifies the telephone number to which calls are to be referred.

Interface	Field Name
IRES	TC TO PRI
FTP	TCTOPRI

USAGE: Refer to Section 3 - End User.

58. TC TO SEC - Transfer of Calls To Secondary Number

Identifies the secondary telephone number to which calls are to be referred.

USAGE: This field is not supported by Sprint LTD.

59. TCID - Transfer of Calls To Identifier

Identifies the sequence of telephone numbers and names associated with split transfer of calls.

USAGE: This field is not supported by Sprint LTD.

60. TC NAME - Transfer of Calls To Name

Identifies the name(s) associated with TC TO PRI and TC TO SEC fields to which calls are to be referred when split transfer of calls is requested.

USAGE: This field is not supported by Sprint LTD.

61. TC PER - Transfer of Calls Period

Indicates the requested date that the transfer of calls, specified in the TC TO PRI field, is to be removed and the standard recorded announcement is to be provided.

Interface	Field Name
IRES	TC PER
FTP	TCPER

USAGE: See Section 3 - End User.

62. LEAN - Line Existing Account Number

Identifies the end user's existing account number assigned by the current NSP and/or LSP.

USAGE: This field is not supported by Sprint LTD.

63. LEATN - Line Existing Account Telephone Number

Identifies the end user's existing account telephone number assigned by the old LSP.

USAGE: This field is not supported by Sprint LTD.

65. SOE REMARKS – SOE Remarks

Identifies information that is to be written directly to the service order (SOE).

Interface	Field Name
IRES	SOE REMARKS
FTP	Not Applicable

NOTE 1: This is Sprint LTD proprietary field.

NOTE 2: The purpose of this field is to allow users to provide information such as driving directions, can be reached numbers and rotary hunt sequences.

USAGE: See usage strip below.

ACTIVITIES											
R E Q		N	C	D	T	V	W	S	B	L	P
	B/LNP	P	P	P	P	O	P	P	P	P	P
	B/INP	P	P	O	P	O	P	P	P	P	P

DATA CHARACTERISTICS: 50 alphanumeric characters

EXAMPLE: N | W | | C | O | R | N | E | R | | O | F | | 5 | T | H | | & | | S |
 | A | N | T | A | | F | E | | B | L | V | D | . | | B | E | H | I | N | D |
 | | T | H | E | | P | I | Z | Z | A | | S | H | O | P | | | | |